

Manual, Assembly instruction: Brodit 855038

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the enclosed Gap Opener (Spaltöffner) into the gap surrounding the center control panel, to widen the gap. Push the Gap Opener (Spaltöffner) leftwards, to find the plastic detail hidden behind the panel that the ProClip needs to be fitted around. Remove the adhesive tape covers from the ProClip. Place the angled top part of the ProClip in its position guided by the Gap Opener (Spaltöffner).

2. Push the Gap Opener (Spaltöffner) rightwards again to make room for the ProClip, and leave it in the gap to widen it. Press the angled top part of the ProClip into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).

3. Press the bottom part of the ProClip downward, so the angled top part hooks behind the panel properly. Press the angled bottom part of the ProClip into the gap underneath of the center console.

4. The ProClip is in place.