

Manual, Assembly instruction: Brodit 855040

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Press the angled Gap Opener (Spaltöffner) into the gap between the air vent and the dash board, to widen the gap.
2. Insert the angled top part of the ProClip into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).
3. Pull the ProClip downward, so the angled top part goes all the way into the gap. Hook the angled bottom part of the ProClip into the gap between the frame surrounding the control panel and center console.
4. The ProClip is in place.