

Manual, Assembly instruction: Brodit 855050

Angled mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap openers into the seem/gap between the center console panel edge and the center console sidewall, to widen the gap.

2. Remove the adhesive tape cover on the ProClip. Press the angled edge on the left side of the ProClip into the seem/gap between the center console panel edge and the inner center console sidewall.

3. Press forward on the right side of the ProClip face plate so the ProClip flexes forward and the angled right edge of the ProClip hooks into the gap between the gap openers. Remove the gap openers.

4. The ProClip is in place.