

Manual, Assembly instruction: Brodit 855052

Angled mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the angled edge on the upper part of the ProClip into the seem/gap between the center console panel edge and the padded dashboard edge. Then flip the ProClip downward so the top angled edge hooks behind the center console panel.

2. Press the lower part of the ProClip upward and hook the lower angled edge into the seem/gap between the silver trim and the padded part of the console.

3. Press down on the inner side of the ProClip to make sure the angled edge is all the way into the gap.

4. The ProClip is in place.