

Manual, Assembly instruction: Brodit 855055

Angled mount For Hybrid models; visually compare dash for match and also see 2014 model.

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the padded console edge and the console sidewall, to widen the gap. Remove the adhesive tape cover on the ProClip.
2. Press the angled right edge of the ProClip into the gap below the gap opener. Remove the gap opener.
3. Flex the left side of the ProClip leftward so the angled edge hooks around the console front edge.
4. The ProClip is in place.