

Manual, Assembly instruction: Brodit 855056

Angled mount ONLY for Jazz Elegance, NOT for Trend, NOT for Comfort.

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the padded part of the dashboard and the silver trim under it, to widen the gap. Open the glove compartment door.

2. Remove the adhesive tape cover on the ProClip. Press/hook the angled lower edge of the ProClip around the lower dashboard edge.

3. Press the upper part of the ProClip forward so the angled upper edge hooks into the gap next to the gap opener. Then press down on top of the ProClip to make sure the angled edge goes all the way into the gap. Remove the gap opener. Close the glove compartment door.

4. The ProClip is in place.