

Manual, Assembly instruction: Brodit 855057

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip. This ProClip consists of two parts.

1. Press the thin end of the enclosed gap opener into the gap between the upper frame around the center console and the top tray, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip.

2. Insert the S-shaped edge on the back part of part 1 into the gap next to the gap opener. Remove the gap opener. Press the front part downward/forward so the front edge flexes down onto the top tray edge. Press so the tape adheres properly.

3. Attach the face plate (part 2) using the included screws.

4. The ProClip is in place.