

Manual, Assembly instruction: Brodit 855062

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the lower edge on the ProClip into the gap between the air vent and the surrounding frame.

2. Hook the angled edge on the upper part of the ProClip under the frame surrounding the air vent.

3. Pull the ProClip toward you so the angled upper edge hooks properly in place and the adhesive tape attaches.

4. The ProClip is in place.