

Manual, Assembly instruction: Brodit 855066

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the angled edge of the upper part of the ProClip over the lower edge of the air vent.
2. Press downward on the ProClip so the angled upper edge goes all the way into the gap.
3. Use the Gap Opener (Spaltöffner) if needed. Press angled edge on the lower part of the ProClip into the gap between the trim and the panel surrounding the stereo. Press the edge firmly upward so it goes all way into the gap and the adhesive tape fastens properly
4. The ProClip is in place.