

Manual, Assembly instruction: Brodit 855067

Angled mount



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Hook the angled lower edge of the ProClip around the upper edge of the air vent.
2. Move the upper edge of the ProClip forward towards the information screen.
3. Press the angled upper edge of the ProClip into the gap between the information screen and dashboard.
4. The ProClip is in place.