

Manual, Assembly instruction: Brodit 855073

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the dashboard and the console around the air vent, to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Hook the lower part of the ProClip under the frame surrounding the air vent.
3. Press the upper part of the ProClip forward so the angled edge hooks into the gap next to the gap opener. Press downward on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.
4. ProClip is in place.