

Manual, Assembly instruction: Brodit 855074

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the compartment and the dashboard, to widen the gap. Press the curved edge on the upper part of the ProClip into the gap next to the gap opener.
2. Press the upper part of the ProClip into the gap, in the same time flip the lower part downward so the angled edge hooks under the compartment.
3. Pull the ProClip toward you and hook the angled edge on the lower part into the gap between the dashboard and the center console. Pull out the gap opener.
4. The ProClip is in place.