

Manual, Assembly instruction: Brodit 855076

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can be placed along the full span of the air vents, but Brodit recommends to place it as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the air vent frame and the dashboard, to widen the gap. Remove the adhesive tape covers on the ProClip.

2. Insert the angled lower edge of the ProClip into the gap between the dashboard overhang and the center console control panel.

3. Press the upper part of the ProClip forward. Press the Gap Opener (Spaltöffner) forward to widen the gap further, at the same time: insert the left corner of the angled edge on the upper part of the ProClip into the gap next to the Gap Opener (Spaltöffner). Insert the remainder of the angled upper part into the gap. Remove the Gap Opener (Spaltöffner).

4. The ProClip is in place.