

Manual, Assembly instruction: Brodit 855082

Center mount, Right

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the angled edge on the upper part of the ProClip into the gap between the air vent and the dashboard. Press firmly downward so the angled edge goes all the way into the gap and hooks properly under the air vent housing.
2. Press the lower part of the ProClip downward so the angled upper edge hooks behind the air vent housing.
3. Hook the angled edge on the lower part of the ProClip into the gap between the control panel and the dashboard.
4. The ProClip is in place.