

Manual, Assembly instruction: Brodit 855084

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the lower part of the ProClip over the frame surrounding the air vent.
2. Press the upper part of the ProClip downward and forward. Hook the angled upper edge of the ProClip under the frame surrounding the air vent.
3. Press the upper part of the ProClip upward and the lower part downward so the adhesive tapes attach properly.
4. The ProClip is in place. This ProClip can also be placed on the left air vent, provided that the installed equipment does not block the instrument panel.