

Manual, Assembly instruction: Brodit 855086

Angled mount NOT for Techno models.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the lower part of the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the angled edge on the right part of the ProClip into the gap above the gap opener. Pull out the gap opener.
3. Press the gap opener into the upper part of the gap between the frame surrounding the air vent and the dashboard. Press the gap opener further into the gap and carefully prize the gap wider. In the same time: Press forward on the ProClip so the angled edge on the left part hooks into the gap below the gap opener. Pull out the gap opener.
4. The ProClip is in place.