

Manual, Assembly instruction: Brodit 855087

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin end of one of the enclosed gap openers into the gap between the frame surrounding the air vent and the control panel, to widen the gap. Press the gap opener further into the gap and carefully prize the gap wider. In the same time: Press the angled edge on the right part of the ProClip into the gap above the gap opener. Pull out the gap opener.

2. Press both gap openers into the gap between the frame surrounding the air vent and the dashboard, one on each side of the ProClip.

3. Press the ProClip leftward and forward so the angled edge on the left part goes all the way into the gap between the gap openers. Pull out the gap openers.

4. The ProClip is in place.