

Manual, Assembly instruction: Brodit 855089

Center mount



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Insert the angled left edge of the ProClip behind the panel on the inside of the air vent.
2. Flex the ProClip rightward by pressing the left part of the ProClip. Insert the angled left part of the ProClip behind the panel on the inside of the air vent.
3. Press both sides of the ProClip outward to make sure the adhesive tapes fasten properly.
4. The ProClip is in place.