

Manual, Assembly instruction: Brodit 855091

Angled mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Insert the thin end of the enclosed gap opener into the gap below the information display, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip.
2. Hook the angled lower edge of the ProClip around the upper edge of the air vent.
3. Flex the ProClip forward and insert the upper angled edge into the gap next to the gap opener. Remove the gap opener.
4. The ProClip is in place.