

Manual, Assembly instruction: Brodit 855098

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip. This ProClip can also be placed on the passengers side.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin ends of the enclosed Gap Opener (Spaltöffner)s into the gap on top of the dashboard, to widen the gap. Remove the adhesive tape cover on the ProClip.

2. Insert the lower angled part of the ProClip into the upper edge of the airvent.

3. Move the ProClip upward + forward so the lower angled part goes all the way into the air vent and the adhesive tape attaches. Press the u-shaped upper part of the ProClip into the gap between the Gap Opener (Spaltöffner)s. Remove the Gap Opener (Spaltöffner)s.

4. The ProClip is in place.