

Manual, Assembly instruction: Brodit 855100

Angled mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the silver trim surrounding the center control panel and the remaining dashboard, to widen the gap. Remove the adhesive tape cover on the ProClip.
2. Insert the upper edge of the ProClip into the gap next to the gap opener.
3. Move the lower part of the ProClip downward so the upper part goes all the way into the gap. Hook the lower edge of the ProClip around the edge of the center console leather trim. Remove the gap opener. Make sure the adhesive tape fastens properly by pressing the lower part of the ProClip upward.
4. The ProClip is in place.