

Manual, Assembly instruction: Brodit 855102

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before attaching the ProClip. Note: After attaching this ProClip the air vent may be tight to adjust.

- 1.** Point the damper in the air vent leftward. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip.
- 2.** Insert the angled left side (the longer side) of the ProClip under the edge of the panel surrounding the center console.
- 3.** Point the damper in the air vent rightward. Press the right side of the ProClip leftward so the angled right edge goes under the edge of the panel surrounding the center console.
- 4.** The ProClip is in place.