

Manual, Assembly instruction: Brodit 855109

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip. Note: This ProClip can be placed on any air vent in the cab.

1. Press the enclosed gap opener into the gap on the top side of the frame surrounding the air vent and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip.

2. Press the angled lower part of the ProClip into the gap on the bottom side of the frame surrounding the air vent and the dashboard.

3. Press the top part of the ProClip upward/forward so the angled edge hooks into the gap next to the gap opener. Remove the gap opener.

4. The ProClip is in place, shown on different locations in the cab.