

Manual, Assembly instruction: Brodit 855110

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Lift the rubber mat on top of the dashboard and locate the small plastic hooks coming from the frontpart of the dashboard.

2. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Place the lower angled edge on the ProClip around the edge of the dashboard.

3. Hook the upper edge of the ProClip around the edge of the dashboard between the plastic hooks.

4. The ProClip is in place.