

Manual, Assembly instruction: Brodit 855113

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap on the top side of the dashboard, to widen the gap. Remove the adhesive tape cover on the ProClip. Push onto the gap opener to keep it in place while inserting the angled top part of the ProClip into the gap next to the gap opener. Remove the gap opener.

2. Pull the bottom part of the ProClip downward/backward so the angled edge goes all the way into the gap.

3. Hook the angled lower part of the ProClip around the edge of the dashboard.

4. The ProClip is in place.