

Manual, Assembly instruction: Brodit 855114

Center mount NOT for leather interior.

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip. It is very important to place the ProClip exactly as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap by the lower edge of the trim, to widen the gap. Remove the adhesive tape cover on the ProClip.

2. Insert the lower angled edge of the ProClip into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).

3. Insert the thin end of the Gap Opener (Spaltöffner) into the gap by the upper edge of the trim, to widen the gap. Hook the angled top part of the ProClip into the gap next to the Gap Opener (Spaltöffner). Make sure the ProClip is placed next to the button for the hazard warning lights. Remove the Gap Opener (Spaltöffner).

4. The ProClip is in place.