

Manual, Assembly instruction: Brodit 855115

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip.
2. Hook the angled right edge of the ProClip around the left console frame.
3. Push forward on the left side of the ProClip flexing the left side so the angled edge hooks around the console edge.
4. The ProClip is in place.