

Manual, Assembly instruction: Brodit 855117

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Align the ProClip above the left air vent. Press the angled edge on the upper part of the ProClip into the gap between the two dashboard sections. Press the upper part downward to make sure the angled edge goes all the way into the gap and under the front panel of the dash.

2. Pull the lower part of the ProClip towards you so that the angled lower edge hooks around the dashboard edge.

3. Press downward/forward on the edges of the ProClip to make sure the adhesive tape attaches properly. Notice: If the ProClip is not aligned to be above the left vent it might not remain attached securely.

4. The ProClip is in place.