

Manual, Assembly instruction: Brodit 855121

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the lower angled edge of the ProClip into the gap between the silver frame surrounding the air vent panel and the panel surrounding the center control panel.
2. Push the top part of the ProClip forward so the angled top edge goes into the gap between the silver frame surrounding the air vent and the padded part of the dash. Press until you hear + feel the ProClip clicking into place.
3. The ProClip is in place.
4. The ProClip is in place.