

Manual, Assembly instruction: Brodit 855123

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Align the ProClip between the start button and the upper left air vent. Press the lower notched edge of the ProClip into the gap between the lower frame surrounding the air vents and the padded center part of the dash.

2. Press the notched upper edge of the ProClip into the gap between upper frame surrounding the air vents and the padded center part of the dash.

3. The ProClip is in place. **4.** The ProClip is in place.