

Manual, Assembly instruction: Brodit 855125

Angled mount



Please read all of the instructions, and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the thin end of the enclosed gap opener into the gap on the right side of the silver trim, to widen the gap.

2. Starting with the lower corner, press the thin left side of the ProClip into the gap above the gap opener. Remove the gap opener.

3. Push the right side of the ProClip forward so the angled left side goes all the way into the gap. Hook the angled right edge of the ProClip into the seam between the padded paneling and the paneling below. Press so the angled edge goes all the way into the gap.

4. The ProClip is in place.