

Manual, Assembly instruction: Brodit 855127

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Insert the curved lower edge of the ProClip into the gap to the left of the glove compartment.

2. Align the edge of the adhesive tape with the silver trim. Push the upper part of the ProClip upward/forward so the tape adheres to the silver trim.

3. Hook the angled upper edge of the ProClip into the gap between the silver trim and the padded part of the dash.

4. The ProClip is in place.