

Manual, Assembly instruction: Brodit 855129

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap surrounding the storage compartment on top of the dash, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip.
2. Hook the angled lower part of the ProClip around the edge on the front of the dashboard.
3. Press the angled upper edge of the ProClip into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).
4. The ProClip is in place.