

Manual, Assembly instruction: Brodit 855131

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the thin end of the enclosed gap opener into the gap between the padded dashboard overhang and the frame surrounding the airvent panel, to widen the gap. Remove the adhesive tape cover on the ProClip.
2. Place the right edge of the ProClip 40 mm from the center pillar dividing the air vent. Insert the milled lower edge of the ProClip into the lower edge of the air vent.
3. Insert the upper angled edge of the ProClip into the gap next to the gap opener. Remove the gap opener.
4. The ProClip is in place.