

Manual, Assembly instruction: Brodit 855132

Angled mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Hold the ProClip so the angled upper edge points upward. Insert the angled upper edge into the gap between the shiny and the matte part of the control panel.
2. Push the lower part of the ProClip downward + forward so the angled upper edge goes all the way into the gap and hooks behind the control panel.
3. Insert the lower angled edge into the gap dividing the control panel from the center console.
4. The ProClip is in place.