

Manual, Assembly instruction: Brodit 855134

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap on the side of the center console wall, to widen the gap.
2. Insert the angled right side of the ProClip into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).
3. Press the Gap Opener (Spaltöffner) into the gap between the multimedia system and the center console, to widen the gap. Press the angled left side of the ProClip into the gap below the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).
4. The ProClip is installed.