

Manual, Assembly instruction: Brodit 855137

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip. This ProClip can also be placed on the right airvent.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Insert the thin ends of the enclosed gap openers into the gap between the air vent panel and the remainder of the dashboard, to widen the gap. Make sure the gap openers are inserted above the decorative light strip (see inlay).

2. Insert the angled lower edge of the ProClip into the gap between the gap openers. Remove the gap openers.

3. Flex the upper part of the ProClip slightly downward so the milled upper edge can be inserted into the upper edge of the air vent.

4. The ProClip is in place.