

Manual, Assembly instruction: Brodit 855144

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Place the thin upper edge of the ProClip into the upper part of the air vent.

2. Flex the lower part of the ProClip upward and hook the grooved edge onto the lower air vent edge.

3. The ProClip is in place.

4. The ProClip is in place.