

Manual, Assembly instruction: Brodit 855145

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip is divided into two parts Part 1: The attaching part (the smallest part) Part 2: The ProClip faceplate

1. Press the thin ends of the enclosed gap openers into the gap between padded part of the dash and the center console frame, to widen the gap. Make sure the lower gap opener is inserted just above the silver/chrome strip (see photo). Insert the thin end of Part 1 into the gap between the gap openers. When Part 1 is all the way into the gap, remove the gap openers.

2. Press the thin end of one of the enclosed gap openers into the gap between the padded part of the dash and the leather paneling surrounding the speedometer, to widen the gap. Insert the L-shaped angled edge of Part 2 into the gap below the gap opener. While making sure the L-shaped edge goes all the way into the gap and hooks behind the panel, rotate the whole Part 2 rightward.

3. Align the holes in Part 2 with the pre-drilled holes in Part 1. Fasten the two parts together using the enclosed screws. Remove the gap opener.

4. The ProClip is in place.