

Manual, Assembly instruction: Brodit 855146

Angled mount Not for Vignale.



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the s-shaped right side of the ProClip into the gap on the center console side wall.

2. Move the ProClip leftward so the right edge of the ProClip goes all the way into gap and hooks behind the panel.

3. Insert the thin end of the enclosed gap opener into the gap between the paneling surrounding the center control panel and the remainder of the center console, to widen the gap. Pull the left side of the ProClip toward you so the angled left edge goes into the gap, below the gap opener. Remove the gap opener.

4. The ProClip is in place.