

Manual, Assembly instruction: Brodit 855148

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap dividing the center control panel, to widen the gap. Remove the adhesive tape cover on the ProClip.
2. Starting with the right corner; insert the lower edge of the ProClip into the gap next to the Gap Opener (Spaltöffner). Press the edge all the way into the gap. Remove the Gap Opener (Spaltöffner).
3. Pull the ProClip upward so the angled upper edge hooks around the lower edge of the air vent.
4. The ProClip is in place.