

Manual, Assembly instruction: Brodit 855150

Angled mount NOT for models with factory navigation.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the thin end of the enclosed Gap Opener (Spaltöffner) into the gap dividing the climate control panel from the remainder of the center console, to widen the gap. Remove the adhesive tape cover on the ProClip. Insert the angled lower edge of the ProClip into the gap next to the Gap Opener (Spaltöffner).
2. Pull the ProClip upward, flexing it so the grooved upper edge hooks into the lower edge of the air vent.
3. Press the lower part of the ProClip inward until you hear + feel it snaps into place. Pull out the Gap Opener (Spaltöffner).
4. The ProClip is in place.