

Manual, Assembly instruction: Brodit 855154

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Hook the angled left edge of the ProClip around the edge of the console sidewall.
2. Press the thin end of the enclosed gap opener into the gap between the panels on the right side of the center console panel, to widen the gap.
3. Press the right side of the ProClip downward until the angled right edge goes into the gap next to the gap opener. Remove the gap opener.
4. The ProClip is in place.