

Manual, Assembly instruction: Brodit 855160

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the dashboard and the console around the air vent, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Starting with one corner, press the angled upper edge of the ProClip into the gap next to the gap opener. Remove the gap opener.

3. Press the thin end of the enclosed gap opener into the gap between the bottom side of the console surrounding the air vent and the dashboard, to widen the gap. Press the ProClip downward/inward so the angled lower edge goes below the padded part of the dash and into the gap next to the gap opener. Remove the gap opener.

4. The ProClip is in place.