

Manual, Assembly instruction: Brodit 855162

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Open the lid of the storage compartment on top of the dashboard. Insert the angled upper edge of the ProClip into the gap between the frame surrounding the storage compartment and the padded inner lining (see detailed picture inlay).

2. and 3. Pull the ProClip backward/downward so the upper edge goes all the way into the gap and the angled lower edge hooks around the dashboard overhang above the air vent.

4. The ProClip is in place.