

Manual, Assembly instruction: Brodit 855163

Angled mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Insert the thin end of the enclosed gap opener into the gap below the center control panel, to widen the gap. Make sure the gap opener is inserted in the front gap, see picture.

2. Insert the lower edge of the ProClip into the gap next to the gap opener.

3. Flip the ProClip upward/forward and insert the angled upper edge into the gap between the frame surrounding the center console control panel and the padded part of the center console.

4. The ProClip is in place.