

Manual, Assembly instruction: Brodit 855164

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Insert the thin end of the enclosed angled gap opener into the gap on the upper side of the air vent, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip.

2. Insert the lower angled edge of the ProClip into the gap between the silver trim and the panel surrounding the air vent.

3. Flex the upper part of the ProClip downward and insert the angled upper edge of the ProClip into the gap next to the gap opener. Remove the gap opener.

4. The ProClip is in place.