

Manual, Assembly instruction: Brodit 855165

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the thin end of the enclosed gap openers into the gap in the center console sidewall, to widen the gap.

2. Hook the right side of the ProClip over the center console edge, placed just above the climate control panel. Press the ProClip all the way forward.

3. Press the left side of the ProClip forward and hook the left angled edge of the ProClip into the gap between the gap openers. Press the front of the ProClip to the right to make sure the edge goes all the way into the gap. Pull out the gap openers.

4. The ProClip is in place.