

## Manual, Assembly instruction: Brodit 855167

Angled mount



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

**1.** Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame around the upper right vent and the padded panel to the right of the frame, to widen the gap. Remove the cover from the adhesive tape on the ProClip.

**2.** Press the angled edge on the right side of the ProClip into the gap below the gap opener.

**3.** Rotate the ProClip to the left making sure the right edge stays into the gap between the vent frame and panel next to it. Flex the left side of the ProClip into the seam between the left vent frame and the silver trim surrounding the center console information screen. Pull out the gap opener.

**4.** The ProClip is in place.