

Manual, Assembly instruction: Brodit 855169

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is very important to place the ProClip in exact the same position as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the ProClip directly to the left of the right button. Press the lower edge of the ProClip into the gap between the center console and the dashboard.

2. Slide the ProClip sideways to the right, until the ProClip is placed 1 cm from the right edge of the center console.

3. Pull the upper part of the ProClip upward and hook the angled edge into the gap between the trim and the dashboard. Press forward on the ProClip so the adhesive tapes attach properly.

4. The ProClip is in place.